User seal checks

Half-face reusable respirators | cartridge

NEGATIVE AND POSITIVE PRESSURE



Breathe in gently

Respirator should slightly **collapse**

If air leaks in around the face:



Breathe out gently

Respirator should slightly **expand**

If air leaks out around the face:



Adjust straps or Reposition face piece



REPEAT TEST UNTIL SEAL IS ACHIEVED